

## Chery New Tiggo 4 PRO Maintenance Schedule

الكيلومترات												بنود الصيانة
10,000 كم	9,000 كم	8,000 كم	7,000 كم	6,000 كم	5,000 كم	4,000 كم	3,000 كم	2,000 كم	1,000 كم	1,000 كم	كم	
R	R	R	R	R	R	R	R	R	R	R		تغيير زيت + فلتر زيت
I	I	I	I	I	I	I	I	I	I	I		فحص وجود تسريب بسوائل المحرك (مياة تبريد، وقود، زيت)
I	I	I	I	I	I	I	I	I	I	I		فحص حالة المحرك علي السلانسيه وفحص بجهاز تشخيص الأعطال
R	I	R	I	R	I	R	I	R	I	I		فلتر الهواء
صيانة مجانية (باستثناء سبب الفشل)												تغيير فلتر الوقود
		R				R						بوجيهات
كل سنتين أو 4,000 كيلومتر (أيهما يأتي أولاً)												تغيير سائل التبريد
كل ثلاث سنوات أو 5,000 كيلومتر (أيهما يأتي أولاً)												فحص وشد سير المجموعة
I	I	I	I	I	I	I	I	I	I	I		فحص الفتيس (تسريب - أضرار)
ال CVT كل سنتين أو 4,000 كيلومتر و ال wet DCT كل ثلاث سنوات أو 6,000 كيلومتر (أيهما يأتي اولاً)												تغيير زيت فتيس
I	I	I	I	I	I	I	I	I	I	I		فحص التيل والطنابير
فحص كل صيانة واستبدال كل 4,000 كيلومتر أو سنتين (أيهما يأتي أولاً)												زيت الفرامل
I	R	I	I	R	I	I	R	I	I	I		فلتر التكييف
I	I	I	I	I	I	I	I	I	I	I		فحص جميع الأنوار وعمل فتحة السقف (في حالة وجود فتحة سقف)
I	I	I	I	I	I	I	I	I	I	I		فحص عمل الكلاكس
I	I	I	I	I	I	I	I	I	I	I		فحص ريش المساحات ومستوي سائل المساحات
I	I	I	I	I	I	I	I	I	I	I		فحص حالة الإطارات وظبط ضغط الإطارات
Rotate	Rotate	R	Rotate	Rotate	Rotate	R	Rotate	Rotate	Rotate			تبدال الإطارات
I	I	I	I	I	I	I	I	I	I	I		فحص وربط منظومة التعليق

فحص I:

تغيير: R



## Chery New Tiggo 4 PRO Maintenance Schedule

Maintenance Items	Kilometers											
	KM	1000 km	10,000 km	20,000 KM	30,000 KM	4,0000 KM	50,000 KM	60,000 km	70,000 KM	80,000 KM	90,000 KM	100,000 KM
Oil & Filter Replacement		R	R	R	R	R	R	R	R	R	R	R
Inspect engine liquids for leakage (coolant, fuel, oil)		I	I	I	I	I	I	I	I	I	I	I
Inspect Engine Idling & operation (with diagnostic tool)		I	I	I	I	I	I	I	I	I	I	I
Air Filter		I	I	R	I	R	I	R	I	R	I	R
Fuel Filter Replacement	Maintenance-free (except for the cause of failure)											
Spark plugs						R				R		
Engine Coolant replacement	Every 2 years or 40000 km (whichever comes first)											
Inspect Drive Belt state and tension	Replace every 3 years or 50000 km (whichever comes first)											
Transaxle: check for leakage or damage		I	I	I	I	I	I	I	I	I	I	I
Change automatic transmission Fluid	For CVT every 40000 km or 2 years and for Wet DCT Replace every 3 years or 60,000 km (whichever comes first)											
Inspect Disc Brakes		I	I	I	I	I	I	I	I	I	I	I
Brake Fluid	Inspect every maintenance and replace every 40,000k km or two years (whichever comes first)											
A/C Filter		I	I	I	R	I	I	R	I	R	I	R
Inspect All Lights Operation and sunroof (If equipped)		I	I	I	I	I	I	I	I	I	I	I
Inspect Horn Operation		I	I	I	I	I	I	I	I	I	I	I
Inspect Wiper Blades Operation& Fluid		I	I	I	I	I	I	I	I	I	I	I
Inspect Tires Condition, Pressure & Adjust		I	I	I	I	I	I	I	I	I	I	I
Tire Rotation			Rotate	Rotate	Rotate	R	Rotate	Rotate	Rotate	R	Rotate	Rotate
Inspect and tighten Suspension		I	I	I	I	I	I	I	I	I	I	I

I:inspect

R:replace

